

**Warnings:**

1. This product is to be installed and serviced by a certified electrician.
2. The Luminaire should be installed in an area with good ventilation, clear of any corrosive or combustible gases and explosive objects.
3. A supply voltage tolerance of +/- 10% is allowable. An improper installation outside of this range or with the incorrect input voltage will influence the normal operation of this luminaire and result in damage to the lamp and electronic ballast.
4. The luminaire must be properly grounded to prevent accidental electrical shocks, and to prevent interference from the electrical ballast affecting the normal operation of the luminaire.
5. Do not open the housing with the luminaire powered on.

**Standard Grid Mount Instruction:**

1. Remove existing lay-in troffer or tile from standard grid ceiling.
2. Drop in new LED flat panel (cable mount brackets are installed on the top side of the fixture at different locations, connect chain or steel cable to brackets for additional support).
3. Open back box cover on the back side of the fixture.
4. Connect power (standard 110V to 277V) to LED Driver inside the back box.
5. Check all connection before energizing fixture.

